

*flex*KRETE

SUPERIOR CONCRETE REPAIR MATERIAL

YOU NO LONGER NEED TO: Cut
THIS out, Haul it off, & Re-pour it,
And Wait & Wait For Days!
OPEN TO TRAFFIC IN MINUTES!



Key-in perimeter, minimum 1/4"

Grind or blast clean to attain a clean, white, rough surface

Use pump-up sprayer or spray bottle to apply thin coat of FlexPrime.



Mix 3 parts aggregate (sand, color quartz, aluminum oxide, etc.),
with 1 part catalyzed FlexKrete,
Hand or power trowel smooth, pull tape,
OPEN TO TRAFFIC!

**747's have actually rolled over FlexKrete for many years,
and on a feather-edged ramp!**



Copyright © 2019 Protective Products Inc. dba FlexKrete Technologies, All rights reserved.

Our mailing address is:

Protective Products Inc. dba FlexKrete Technologies

881 N Louisiana Dr

Celina, TX 75009